


## Supervisory Unit PAN - D

Operating manual

Version  
21.01.2004/94a

Software-Version  
\_\_\_\_\_



Issue GB  
Edition 01.2004

## Supervisory Unit PAN - D

### Operating manual

Version 21.01.2004

Copyright 2004 by **A. Eberle GmbH & Co. KG**. All rights reserved.

Published by:

**A. Eberle GmbH & Co. KG**

Frankenstraße 160

90461 Nuremberg, Germany

Tel: +49 (0) 911 / 62 81 08 - 0

Fax No.: +49 (0) 911 / 62 81 08 - 96

e-mail: [info@a-eberle.de](mailto:info@a-eberle.de)

Internet: [www.a-eberle.de](http://www.a-eberle.de), [www.regsys.de](http://www.regsys.de)

The company **A. Eberle GmbH & Co. KG** cannot be held liable for any damages or losses emitting from printing errors or changes in this operating manual.

Furthermore, **A. Eberle GmbH & Co. KG** does not assume responsibility beyond the guarantee period for any damages and losses resulting from deficient devices or from devices changed by the applicant.

## Index

<b>1</b>	<b>Warnings and Notes</b>	<b>6</b>
<b>2</b>	<b>Application</b>	<b>7</b>
<b>3</b>	<b>Delivery Contents</b>	<b>8</b>
<b>4</b>	<b>Technical Data</b>	<b>9</b>
4.1	Plug-in group	9
4.2	Contact assignment	11
4.2.1	Terminal Block 1; (Binary Outputs BA)	11
4.2.2	Terminal Block 2; (Binary Inputs BE)	12
4.2.3	Terminal Block 3; (Measuring Voltage, Auxiliary Voltage)	13
4.2.4	Terminal Block 5; (Messages)	14
4.2.5	Terminal Block 6; (E-LAN)	15
4.2.6	Interface COM 1	16
4.2.7	Pin assignment of the terminal blocks	17
4.3	Rack Mounting	18
4.4	Wall Mounting rack, type 30 TE	18
4.5	Wall rack, type 30 TE for panel mounting	19
4.6	Parameterization, Configuration of the PAN-D	21
4.6.1	With REG-D	21
4.6.2	With PC	22
<b>5</b>	<b>Description</b>	<b>23</b>
5.1	Interface COM 1	23
5.2	E-LAN (Energy-Local Area Network)	23
<b>6</b>	<b>Operation</b>	<b>24</b>
6.1	Indication and Operation Elements	24
<b>7</b>	<b>Supervisory Functions</b>	<b>26</b>
7.1	Supervision of the PAN-D (Self-surveillance)	26
7.2	Supervision of the line voltage	26
7.3	Supervision of the tap-changer	30
7.4	Supervision of the regulator REG - D	32
7.5	Operation Principle	34
7.6	Selection of the indication mode	35
7.7	Lamp Check / CPU - Test	35

<b>8</b>	<b>Basic Settings</b>	<b>36</b>
8.1	General	36
8.1.1	Identification Signal (User ID)	36
8.1.2	Set Time/Date	37
8.1.3	Password	38
8.1.4	Actual Value Correction of Measuring Voltage $U_E$	39
8.2	RS-232 Interfaces	40
8.2.1	Interface COM 1	40
8.2.2	Interface COM 2	41
8.3	E-LAN (Energy-Local Area Network)	43
8.4	Status (present data of the supervisory unit PAN - D)	44
<b>9</b>	<b>Parameterization of the supervisory unit PA N -D</b>	<b>45</b>
9.1	< U1 Undervoltage	46
9.2	Time Delay < U1 Undervoltage	46
9.3	> U2 Overvoltage	46
9.4	Time Delay < U2 Overvoltage	46
9.5	<< U3 Undervoltage	47
9.6	Time Delay << U3 Undervoltage	47
9.7	>> U4 Overvoltage	47
9.8	Time Delay >> U4 Overvoltage	47
9.9	Trigger	48
9.10	Time Delay Trigger	48
9.11	Functions	49
9.11.1	Maximum Time of Tap-changer in operation	49
9.11.2	Measuring (of the net voltage)	49
9.11.3	Limit Value Reference (Reference quantity)	50
9.11.4	PAN - D Deactivation	51
9.12	Input Assignments (Binary Inputs)	52
9.13	Relay Assignments	53
9.14	LED Assignments	54
<b>10</b>	<b>Update of the Operation Software</b>	<b>55</b>
10.1	Preparing the PC	56
10.1.1	Operation System Windows 3.x	56
10.1.2	Operation System Windows 95/98	57
10.2	Start Prime Load	58
<b>11</b>	<b>Maintenance and Current Consumption</b>	<b>60</b>
11.1	How to change fuses	60
11.2	Current Consumption PAN - D	61

12	Definition of Abbreviations .....	62
13	Index .....	63

# 1 Warnings and Notes

The supervisory unit PAN - D is exclusively designed for application in installations and equipment of the electrical engineering in which only trained experts are permitted to do all required works. Experts are persons who are familiar with the installation, mounting, putting into operation and the operation of products of this kind. Furthermore experts have qualifications which comply with their field of work.

The supervisory unit PAN - D has been built and tested in accordance with all important electrical safety regulations and left the factory in perfect condition. To maintain this condition and to guarantee safe operation, the following instructions and warnings in this Operating Manual must be observed.

- ☐ The supervisory unit PAN - D has been built in compliance with IEC 10110/EN61010 (DIN VDE 0411), accuracy class I and checked on this norm before delivery.
- ☐ The supervisory unit PAN - D may only been operated with a connected non-fused earthed conductor. This condition is complied with the connection to an auxiliary voltage line net with a non-fused earthed conductor (European net). Should the auxiliary voltage line net have no non-fused earthed conductor, it is absolutely necessary to make an additional connection from the earth-conducting terminal to the earth.
- ☐ The upper limit of the admissible auxiliary voltage  $U_{AUX}$  must not be exceeded neither permanently nor for a short while.
- ☐ Before changing the fuses separate the supervisory unit PAN - D completely from the auxiliary voltage  $U_{AUX}$ . Any use of other fuses than those being of the given type and current intensity is prohibited.
- ☐ A supervisory unit PAN - D which shows a visible damage or a clear malfunction must not be used and has to be secured against unintentional on-switching.
- ☐ Maintenance and repair works which are made when the lines of the supervisory unit PAN - D are laid bare may only be made by authorized experts.

## 2 Application

An additional supervision of the function of the voltage regulator REG-D and of the function of the tap-changer through the separated autonomous supervisory unit PAN - D increases the safety of the voltage regulation because all setting commands of the regulator are made by contacts of the supervisory unit PAN - D (UND-link, setting command blocking) and because these setting commands will only be passed on to the tap-changer if the switching status are in strict conformance with each other.

In addition to that, the three phase voltages of the net are controlled at the input of the supervisory unit PAN - D and a message will be given if there is a voltage drop.

The supervisory unit PAN - D may be firmly assigned to a regulator REG - D and linked to the regulator by bus (E-LAN) or it may work completely independent from the regulator REG - D.

For additional user-specific controls, supervisions and messages, binary signals may be edited by means of an LED or contact. The operation guide (background program!) of the transformer may thus be made clearer.

### 3 Delivery Contents

1 piece supervisory unit PAN - D


1 piece operation manual in English



## 4 Technical Data


### 4.1 Plug-in group

front plate	plastic, RAL 7035 light-grey
height	3 U (128.5 mm)
width	28 T (142.2 mm)
weight	≤ 1.5 kgs
protection class	
plug-in group	IP 00
terminal block	IP 00
mounting	acc. to DIN 41494 part 5
plug-in connectors	DIN 41612




Dimensions

**Position of the  
Pin-Edge Connectors**



**Position of the  
Terminal Blocks**




## 4.2 Contact assignment

### 4.2.1 Terminal Block 1; (Binary Outputs BA)

### Terminal Block 1 (Binary Outputs BA)


Function	Assign.	Pin	Assign.	Pin
Trigger power switch (2 contact pairs) 2 close	pole	b2	close	z2
	pole	b4	close	z4
Emergency-OFF tap- changer (2 contact pairs) 2 close	pole	b8	close	z8
	pole	b10	close	z10
Higher	pole	b14	close	z14
Lower	pole	b16	close	z16
Programmable	pole	b20	close	z20
Operation / Distortion Turn	pole	b22		
	distortion	b24	operation	z22
Programmable	pole	b26	close	z24
Programmable Binary outputs (BA) 4-semiconductor-relay	poleBA1..4	z28		
	open BA1	b30	open BA3	z30
	open BA2	b32	open BA4	z32



Terminal Block 2  
(Binary Inputs BE)

4.2.2 Terminal Block 2; (Binary Inputs BE)


Function	Assign.	Pin	Assign.	Pin
Tap-changer in operation	+	b2	-	z2
Free to configure	+	b4	-	z4
Free to configure	+	b6	-	z6
Free to configure	+	b8	-	z8
Free to configure	+	b10	-	z10
Free to configure	+	b12	-	z12
Free to configure	+	b14	-	z14
Free to configure	+	b16	-	z16



## 4.2.3 Terminal Block 3; (Measuring Voltage, Auxiliary Voltage)

Function	Assign.	Pin
Measuring Voltage $U_E$	L1	20
	L2	22
	L3	24
Auxiliary Voltage (AC/DC) $U_{AUX}$	L (+)	28
	N (-)	30
	Earth	32


## Terminal Block 3 (Measuring Voltage, Auxiliary Voltage)



Terminal Block 5  
(Messages)

4.2.4 Terminal Block 5; (Messages)


Function	Assign.	Pin	Assign.	Pin
Distortion tap-changer	pole	b2	Close	z2
			Open	b4
Distortion regulator	pole	b6	Close	z6
			Open	b8
< U1	pole	b10	Close	z10
			Open	b12
> U2	pole	b14	Close	z14
			Open	b16
<< U3	pole	b18	Close	z18
			Open	b20
>> U4	pole	b22	Close	z22
			Open	b24
High-speed switching	pole	b26	Close	z26
			Open	b28
programmable	pole	b30	Close	z30
			Open	b32



4.2.5 Terminal Block 6; (E-LAN)

Terminal Block 6  
(E-LAN)


Function	Assign.	Pin	Assign.	Pin
E-LAN	left EA +	b6	right EA +	z6
	left EA -	b8	right EA -	z8
	left E +	b10	right E +	z10
	left E -	b12	right E -	z12



Interface COM 1


4.2.6 Interface COM 1

Function	Pin
DCD	1
RXD	2
TXD	3
DTR	4
Signal Ground	5
DSR	6
RTS	7
CTS	8
RI	9







#### 4.2.7 Pin assignment of the terminal blocks



### 4.3 Rack Mounting

**Caution!**   
Plug-in-rack must be grounded!  


Each plug-in rack is provided with space for 84 units and thus for 84 place numbers „n“. Each single place number is the point of reference for the mounting of the aligning plugs and the connection elements at the back of the rack.

**Place numbers**

Terminal block	1	2	3	4	5	6
Screws	n	n+4	n+8	n+11	n+16	n+25
aligning plugs	n	-	-	-	-	n+26

### 4.4 Wall Mounting rack, type 30 TE

**How to mount PAN - D**

The supervisory unit PAN - D is, after the transparent cover has been opened, put into the case and fixed by the four screws on its front plate.

To wire the supervisory unit PAN - D, the light-grey part of the surface mounting case may be opened to the left or to the right. To do this, please unfasten the corresponding grub screw and pull out the hinge pin.


**Dimensions of the wall mounting rack**

Material	plastic, RAL 7035 light-grey
Height	193 mm
Width	214 mm
Weight	< 1.5 kg
Protection Class	IP 00
Mounting Location	any
Connection Terminals	AMP connectors

## Hole distance for the wall-mounting

Width: 200 mm

Height: 120 mm



## 4.5 Wall rack, type 30 TE for panel mounting

### Mounting assistance

- ⇒ Mark mounting location of the guide rail in screw-hole rail clearly
- ⇒ Carefully bring out the guide rails by means of a screwdriver
- ⇒ Untighten and remove all 4 screws at the outer edges
- ⇒ Pull off upper case part with cover
- ⇒ Remove ground line
- ⇒ Let upper case part slide through the panel section
- ⇒ Turn all 4 laterally fixed claws by 90°
- ⇒ Clamp the upper case part with the corresponding 4 screws from the front into the panel board
- ⇒ Reconnect ground line of the case from the back
- ⇒ Push lower case part onto upper case part

- ⇒ Fix both case parts with the 4 screws at the outer edges (slot-screw at the left, screw-part with internal thread at the right)
- ⇒ Mount guide rails

**Dimensions for the panel section**

Width: 184.5 + 0.2 mm

Height: 138.3 + 0.2 mm

## 4.6 Parameterization, Configuration of the PAN-D

### 4.6.1 With REG-D


If the supervisory unit PAN - D is to be operated by the keyboard and the LC-display of the regulator REG - D, it will be necessary to link PAN - D and REG - D by system bus (E-LAN). Normally, a two-wire twisted line is sufficient.

Due to the fact that the supervisory unit PAN - D is always assigned to a certain regulator, this link restricts the permissiveness of the bus assignment, which had been valid for the total system before this link.

#### Link PAN - D to REG - D

Connection of the link line

The link line must be connected from the right bus terminal (terminal block 6, connection z6, z8) of the supervisory unit PAN - D to the left bus terminal of the regulator (terminal block 6, connection z6, z8).



#### Note

On the 2-wire-connection between REG - D and PAN - D, there must not be any further connections of regulators or supervising units.

Therefore both interfaces must be operated isolatedly, e.g. the matching resistors for the interfaces must be switched to position 'ISOLATION terminated' in both instruments (see E-LAN, operating manual REG - D).

#### **4.6.2 With PC**

If the supervisory unit PAN - D works completely independently from the regulator REG - D, the configuring and parameterizing software WinREG may be used to parameterize by PC (interface COM 1 of the PAN - D).

##### **How to put into operation**

The supervisory unit PAN - D will be ready for operation if the auxiliary voltage U AUX (=U H) is available. The readiness for operation is indicated through the illumination of the LED 'OPERATION'.

##### **Giving of the address**

After the putting into operation, the regulator gives the PAN - D address automatically. To do this, the regulator increases its own address by 1 and passes this new address on to the supervisory unit PAN - D.

##### **Example**

Address of the regulator: A	→ Address PAN - D: A1
Address of the regulator: C9	→ Address PAN - D: D

##### **How to exchange the data**

Without any further steps, PAN - D communicates with the regulator (taking from the regulator: present setpoint value, transmission ratio K<sub>nu</sub> of the voltage transformer, tap-change position and operation mode HAND / AUTOMATION) - provided that no other E-LAN participant at the E-LAN has this address.

A flashing of the LED 'OPERATION' in the regulator indicates colliding addresses. In this case of a collision of addresses, the interrupting E-LAN participant must be set to another address.

After having settled the collision, the flashing may be continued for a maximum of 20 s.

## 5 Description

### 5.1 Interface COM 1

The serial interface COM 1 is at the front of the supervisory unit PAN - D and offers the possibility of coupling a PC, a terminal or a modem.


For technical data and pin assignment please page 16

### 5.2 E-LAN (Energy-Local Area Network)

Please refer to the operating manual of REG - D

## 6 Operation

### 6.1 Indication and Operation Elements



#### Test

For lamp and CPU-Test (see "Lamp Check / CPU - Test" on page 35), For starting the prime load (see page 58) and For acknowledging messages (see page 31 and page 32).



## LC-Display of the voltage regulator REG - D

Address at bus (user Identification)	regulator name	Time
Identification line	09:24:56	
Status line	PAN-D	
<b>„ACTUAL VALUE“</b> in capital letters = simulation of measuring value active	Setpoint	100.0 % 100.0 V 0.0 V
<b>„actual value“</b> in small letters = simulation of measuring value inactive	Act. Value	
	<U1	-5.0 % (2s)
	>U2	15.0 % (5s)
	<<U3	-10.3 % (2s)
	>>U4	10.0 % (8s)
	Inhibit	
	High	25.0 % (10s)
	SETUP : MENU key	

Regulative Deviation

## 7 Supervisory Functions

### 7.1 Supervision of the PAN-D (Self-surveillance)

<b>Operation</b> (green)	
Flashes	No communication with the corresponding regulator possible or collision of addresses
Illuminates	Operation without disturbances Exception: Illuminates with operating prime load and flashes when receiving data
OFF	Internal disturbances

<b>Disturbance</b> (red)	
Flashes	---
Illuminates	Internal disturbances
OFF	Operation without disturbances Exception: Illuminates with operating prime load

### 7.2 Supervision of the line voltage

<b>Phase fall</b> (red)	
Flashes	---
Illuminates	After 2 s time delay, if, in three-phase measuring, not all phase voltages (L1, L2, L3) are available at the input of the PAN - D Precondition: Switch 'Measuring 3-phase' (Functions-1) selected
OFF	In three-phase measuring, all three phases are available

<p>&lt; <b>U1</b> (red); limit value transmitter &lt; U 1 undervoltage          setting range: <math>0.75 X_0 \leq G1 \leq 1.00 X_0</math>          (<math>X_0</math>: reference quantity for the limit value) when undershoot <math>U &lt; G1</math></p>	
Flashes	---
Illuminates	<p>The limit value is <b>undershot</b> and the time delay has expired. The setting commands LOWER (R4) are blocked;          At the same time relay R13 (high-speed switching) is activated.</p>
OFF	Actual value > U1

## Note

The necessary wiring from the regulator to the supervisory unit has to be made by the user.  
 If needed, the limit value may be laid to a binary output (R5,R6,R14 or BA1 ... BA 4).

<p>&gt; <b>U2</b> (red); limit value transmitter &lt; U 2 overvoltage          setting range: <math>1.00 X_0 \leq G2 \leq 1.25 X_0</math>          (<math>X_0</math>: reference quantity for the limit value) when undershoot <math>U &gt; G2</math></p>	
Flashes	---
Illuminates	<p>The limit value is <b>overshot</b> and the time delay has expired. The setting commands HIGHER (R3) are blocked;          At the same time relay R13 (high-speed switching) is activated.</p>
OFF	Actual value < U2

## Note

The necessary wiring from the regulator to the supervisory unit has to be made by the user.  
 If needed, the limit value may be laid to a binary output (R5,R6,R14 or BA1 ... BA 4).

<p>&lt;&lt; <b>U3</b> (red); limit value transmitter &lt;&lt; U 3 undervoltage          setting range: <math>0.65 X_0 &lt; G3 &lt; 1.00 X_0</math>          (<math>X_0</math>: reference quantity for the limit value)          when undershoot U &lt;&lt; G3</p>	
Flashes	---
Illuminates	<p>The limit value is <b>undershot</b> and the time delay has expired.          At the same time, the LED 'Disturbance regulator' is illuminated.          The supervisory unit PAN - D edits the message 'DISTURBANCE regulator' (R8).          The limit signal may be laid to a binary output (R5, R6, R14 or BA1 ... BA 4).</p>
OFF	Actual value > U3

<p>&gt;&gt; <b>U4</b> (red); limit value transmitter &gt;&gt; U 4 overvoltage          setting range: <math>1.00 X_0 &lt; G4 &lt; 1.35 X_0</math>          (<math>X_0</math>: reference quantity for the limit value)          when undershoot U &gt;&gt; G4</p>	
Flashes	---
Illuminates	<p>The limit value is <b>overshot</b> and the time delay has expired.          At the same time, the LED 'Disturbance regulator' is illuminated.          The supervisory unit PAN - D edits the message 'DISTURBANCE regulator' (R8).          The limit signal may be laid to a binary output (R5, R6, R14 or BA1 ... BA 4).</p>
OFF	Actual value < U4

Trigger power switch (red); limit value transmitter 'trigger' setting range: $1.00 X_0 < G5 < 1.35 X_0$ ( $X_0$ : reference quantity for the limit value) when undershoot $U > G5$	
Flashes	---
Illuminates	The limit value is exceeded and the time delay has expired. If required, the limit signal may be laid to a binary output (R5,R6,R14 or BA1 ... BA 4).
OFF	Power switch operations in perfect condition

## Notes to limit value transmitter

### Time delay

The temporal difference between the reaching of the limit value and the signal edit is defined as time delay. For each limit value transmitter, there may be the selection (parameterization) of its own time delay.

### Switching hysteresis, switching difference $X_{sd}$

The difference of the input quantity between the switching on and off of the limit signal after the limit value reaching has disappeared, is defined as switching difference. The switching difference  $X_{sd}$  has a unified value of 1 % of 100 V (which corresponds to 1 V).

### Setting the limit values/Plausibility check

In each limit value transmitter, the limit value may be set at any requirement within a given range. Therefore, the user must check the logical references of the values between themselves.

### Reference quantity $X_0$ and reference value for the limit values

The upper and the lower limit value may be fixed as a relative value in % of the reference quantity  $\Delta U$  [%] or as an absolute value in  $\Delta U$  [V] in reference to the nominal value of the voltage  $U_{nom}$ .

### Example relative limits

If the reference quantity „setpoint value  $X_R$ “ is selected, all limit values will change relatively to the corresponding setpoint value.

Setpoint value:  $X_R = 102.0 \text{ V}$ ; Limit values:  $\pm 10 \%$ ;

Therefore the upper limit is  $112.2 \text{ V}$  or the lower limit  $91.8 \text{ V}$ .

### Example absolute limits

Provided that the reference quantity „ $U_{nom} = 100 \text{ V}$ “ is selected, the limit values refer to the nominal voltage of  $100 \text{ V}$  and are thus independent from the present setpoint value.

Reference quantity:  $U_{nom} = 100 \text{ V}$ ; Setpoint value:  $105 \text{ V}$ ;

Limit values:  $\pm 10 \%$  of  $U_{nom}$ ;

thus the upper limit is  $90 \text{ V}$  or the lower limit  $110 \text{ V}$ .

## 7.3 Supervision of the tap-changer

<b>Tap-changer in operation (red)</b>	
Flashes	---
Illuminates	Signal available at binary input 1 (TAP-CHANGER IN OPERATION)
OFF	Unswitched or no signal at binary input 1 (TAP-CHANGER IN OPERATION)

<b>Disturbance Tap-changer (red)</b>	
Flashes	---
Illuminates	TAP-CHANGER IN OPERATION-error
OFF	Tap-changer operates in perfect condition

Emergency OFF Tap-changer (red)	
Flashes	---
Illuminates	<p><b>Up to software version 1.74</b> TAP-CHANGER IN OPERATION-error Or Grading in the wrong direction</p> <p><b>From software version 1.75</b> on Running time of the motor drive longer than the set time (SETUP 3 'Functions') and the limits &lt;U1 or &gt;U2 are undershot respectively exceeded</p>
OFF	Tap-changer operates in perfect condition

## Note

The LED indicates the error status as described, relay R2, however, starts up for 3 s on appearing of the error but then drops again (impulse relay function).

## Acknowledgement of messages

LED „OFF“

- ⇔ from change of operation mode HAND to operation mode AUTOMATION
- ⇔ when striking key „TEST/RESET“

7.4 Supervision of the regulator REG - D

<b>Disturbance regulator</b> (red)	
<b>Note</b> The regulator is only controlled in operation mode AUTOMATION	
Flashes	---
Illuminates	Limit value reaching of << U3 or >> U4
OFF	When bringing the regulator to a standstill or when the voltage is within the limits of <<U3, >>U4

Acknowledgement of messages

LED „OFF“

- ↔ from change of operation mode HAND to operation mode AUTOMATION
- ↔ when striking key „TEST/RESET“

Programmable message boxes with LEDs

The programmable message boxes display free programmable events (see “LED Assignments” on page 54).



Function keys (F1 ... F5) on REG - D

To select the device function and to parameterize the supervisory unit PAN - D.




Auto

Supervisory functions of the PAN - D run automatically with set parameters.



## Hand (Manual operation)

To parameterize the PAN - D. No other changes are accepted than changes made in operation mode „HAND (MANUAL OPERATION)“  .



## ESC (Abort)

To return from the „**SETUP**“-menus.



## Arrow keys

To increment or decrement the simulated measuring values during the integral measuring value simulation (see operating manual REG - D).



## MENU

To switch to the different indication modes and to the „**SETUP**“-menus of the voltage regulator REG - D and to the supervisory unit PAN - D.




## Return

To confirm a changed parameter in the „**SETUP**“-menu points (see page 45). Changes of parameters are not valid before being confirmed by „Return“.



## Serial interface COM1














To link the voltage regulator to external devices




## 7.5 Operation Principle

The operation of the supervisory unit PAN - D is made by means of the voltage regulator REG-D, is totally menu-guided and, as a rule, the same for each menu-point of „**SETUP**“.

Should parameters be set or changed, please apply to the following operation scheme:

- ⇔ „HAND (MANUAL OPERATION)”  changes to manual operation
- ⇔ „MENU”  poll the list of operation modes
- ⇔ „MENU”  select menu point „**SETUP**”
- ⇔ „MENU”  may be used to turn the pages of the menu selection „**SETUP**” until the required parameter appears on the display.
- ⇔ Select parameter by corresponding function key („F1“ ... „F5“).
- ⇔ Set value of the parameter by the function keys.
  - „F1”  increments the value in large steps
  - „F2”  increments the value in small steps
  - „F4”  decrements the value in small steps
  - „F5”  decrements the value in large steps
- ⇔ „F3”  is reserved for special functions in some „**SETUP**” menus.
- ⇔ If the insertion of a value is finished, the changed value will have to be confirmed by „RETURN” .
- ⇔ Insert password (see “Password” on page 38).
- ⇔ Return or leave the „**SETUP**” menus by „ESC (ABORT)” 
- ⇔ Menus „**SETUP**” will automatically be left if no key is pressed down for approx. 15 seconds.
- ⇔ If the required parameters are typed in, checked and each one confirmed by „RETURN”  the regulator REG-D will be in a position to return to operation mode „AUTO” .

## 7.6 Selection of the indication mode

After striking key „MENU“  several times, the indication modes of the supervisory unit PAN - D may be selected in the **SETUP** menu 6 of the voltage regulator REG-D.

A: REG-D 09:24:56	
SETUP	General
--6--	
	RS-232
	E-LAN
	Al: PAN-D
	Status

### Note

If parameters of the PAN - D are monitored, then there is a short line continuously displayed within the upper double lines on the display.

This is to show that the bus link between REG - D and PAN - D is in perfect condition.

After approx. 5 minutes the display will automatically switch back to the voltage regulator REG - D.

The display shows the set setpoint value, the present actual value as well as the set limit values.

Al:dew-2 09:24:56	
PAN-D	
Setpoint	100.0 %
Act. Value	100.0 U
	0.0 U
<U1	-5.0 % (2s)
>U2	15.0 % (5s)
<<U3	-10.3 % (2s)
>>U4	10.0 % (8s)
Inhibit	
High	25.0 % (10s)
SETUP : MENU key	

### Note


If the display monitors the term „**Actual Value**“ as „**ACTUAL VALUE**“ in capital letters, the „MEASURING VALUE SIMULATION“ will be online.

Please see operation manual of REG-D.

⇨ „MENU“  selects the „**SETUP**“ menu 1 of supervisory unit PAN - D

**Setup-menus**

## 7.7 Lamp Check / CPU - Test

⇨ To check the functions of the light-emitting diodes on the front-panel and the CPU, please strike key „TEST“  .

## 8 Basic Settings

Al:dew-2 09:24:56	
SETUP	General
4	
	RS-232
	E-LAN
	Status

In „**SETUP**“-menu 4“ all basic settings may be defined and modified.

### 8.1 General

Al:dew-2 09:24:56	
SETUP	General
4	
	RS-232
	E-LAN
	Status

F1

➡

Al:dew-2 09:24:56	
General	.. 2
1	
	Station Name
	Time Settings

#### 8.1.1 Identification Signal (User ID)

Al:dew-2 09:24:56	
General	.. 2
1	
	Station Name
	Time Settings

F3

➡

Al:dew-2 09:24:56	
Edit:	abc
Station Name	A/a
dew-2	
d :OK	
ESC :Escape	INS
MENU:Char_list	
F3 :Clipboard	
↔↑↓:Select/Set	DEL

Al:dew-2 09:24:56	
Edit:	abc
Station Name	A/a
dew-2	
d :OK	
ESC :Escape	INS
MENU:Char_list	
F3 :Clipboard	
↔↑↓:Select/Set	DEL

F1

➡

Al:dew-2 09:24:56	
↔↑↓ Character Sel.	
0	1 2 3 4 5 6 7 8 9
A	B C D E F G H I J
K	L M N O P Q R S T
U	V W X Y Z ä ö ü ß
.	+ - / * = _ ° @
F1: abc	F2: A/a

<div> <div>Al:dew-2 09:24:56</div> <div>↔↑↓ Character Sel.</div> <div> 0 1 2 3 4 5 6 7 8 9  A B C D E F G H I J  K L M N O P Q R S T  U V W X Y Z Ä Ö Ü ß  . + - / * = _ ° @ </div> <div> f1: abc   f2: A/a       </div> </div>	<div>F1</div> <div>→</div>	<div> <div>Al:dew-2 09:24:56</div> <div>↔↑↓ Character Sel.</div> <div> ! " # \$ % &amp; ' ( )  * + , - . / 0 1 2 3  4 5 6 7 8 9 : ; &lt; =  &gt; ? @ [ \ ] ^ _ ` {    } ~ ¢ ü é à ä å </div> <div> f1: abc   f2: A/a       </div> </div>
---	----------------------------	--


<div> <div>Al:dew-2 09:24:56</div> <div>↔↑↓ Character Sel.</div> <div> 0 1 2 3 4 5 6 7 8 9  A B C D E F G H I J  K L M N O P Q R S T  U V W X Y Z Ä Ö Ü ß  . + - / * = _ ° @ </div> <div> f1: abc   f2: A/a       </div> </div>	<div>F2</div> <div>→</div>	<div> <div>Al:dew-2 09:24:56</div> <div>↔↑↓ Character Sel.</div> <div> 0 1 2 3 4 5 6 7 8 9  a b c d e f g h i j  k l m n o p q r s t  u v w x y z ä ö ü ß  . + - / * = _ ° @ </div> <div> f1: abc   f2: A/a       </div> </div>
---	----------------------------	---

<div> <div>Al:dew-2 09:24:56</div> <div> <div>Edit:</div> <div>Station Name</div> <div>dew-2</div> <div> :OK  ESC:Escape  MENU:Char_list  f3:Clipboard  ↔↑↓:Select/Set </div> <div> INS  DEL </div> </div> </div>	<div>F3</div> <div>→</div>	<div> <div>Al:dew-2 09:24:56</div> <div> <div>CLIPBOARD</div> <div> CLEAR Entry  PASTE from Clb  COPY to Clipb </div> <div>ESC:Escape</div> </div> </div>
---	----------------------------	---

## 8.1.2 Set Time/Date

<div> <div>Al:dew-2 09:24:56</div> <div> <div>General</div> <div>..2</div> <div>Station Name</div> <div>Time Setting</div> </div> </div>	<div>F4</div> <div>→</div>	<div> <div>Al:dew-2 09:24:56</div> <div> <div>Time/DATE SETTING</div> <div>↑</div> <div>TIME: 10:13:50</div> <div>DATE: 24.09.98</div> <div> ↑↓: Set  ↔↑↓: Select  f5: Seconds=00 </div> <div> ↓  ←  →  0s </div> </div> </div>
--	----------------------------	---

8.1.3 Password



**Note**

User 1 may change all passwords whereas every other user is only able to change his own password!

Delete Passwords

Insert „111111“.


The deletion of the password will only be possible if user 1 has 'opened' the device with his password!

**Note**


When user 1 deletes a password, he switches the complete password poll off (even for the other users!).

User 2 to 5 only delete each corresponding password

Poll Password




## Wrong Password

A1:dew-2		09:24:56	
1	Password Entry	•	<div style="border: 1px solid black; padding: 5px; display: inline-block;">F3</div> 
2	User 1	•	
3	=----	•	
4	*****	•	
5	* Wrong Password *	•	





Insert correct Password

## 8.1.4 Actual Value Correction of Measuring Voltage $U_E$


A1:dew-2		09:24:56		
General --2--	..1	<div style="border: 1px solid black; padding: 5px; display: inline-block;">F5</div> 	Setting the Actual Value Correction	+1.0
	Password		VOLTAGE	+0.1
			-6.7 %	
			=====	
Actual Value Correction			[ -20% +20% ]	-0.1
			(Act.Val=0.0 U)	-1.0

8.2 RS-232 Interfaces




8.2.1 Interface COM 1







## 8.2.2 Interface COM 2



Al: dew-2		09:24:56				PARITY	
-SETUP- RS232 COM-2	COM-1/2					---	
	MODE						
	ECL					PARITY	
	BAUDRATE					even	
	9600						
PARITY				F4 →			
OFF							
HANDSHAKE							
RTS/CTS							

Al: dew-2		09:24:56				HANDSHAKE	
-SETUP- RS232 COM-2	COM-1/2					RTS/CTS	
	MODE						
	ECL					HANDSHAKE	
	BAUDRATE					Xon/Xoff	
	9600						
PARITY				F5 →			
OFF							
HANDSHAKE							
RTS/CTS							

## 8.3 E-LAN (Energy-Local Area Network)

A1:dew-2 09:24:56		F3 →	A1:dew-2 09:24:56	
SETUP	General		-SETUP-E-LAN	BAUDRATE
--4--			L	MODE
	RS-232		LEFT [ ]	2-Wire
	E-LAN		L TERMINATOR	yes
			RIGHT [ ]	R MODE
				2-Wire
	Status		R TERMINATOR	yes

A1:dew-2 09:24:56		F1 →	A1:dew-2 09:24:56	
-SETUP-E-LAN	BAUDRATE		-SETUP-E-LAN	MODE
L	MODE		L	BAUDRATE
LEFT [ ]	2-Wire		LEFT [ ]	125K
L TERMINATOR	yes		REG-D RIGHT [x]	R BAUDRATE
RIGHT [ ]	R MODE			62K5
	2-Wire			
R TERMINATOR	yes			

A1:dew-2 09:24:56		F2 →	BAUDRATE	
-SETUP-E-LAN	MODE		62K5	
L	BAUDRATE		BAUDRATE	
LEFT [ ]	125K		125K	
REG-D RIGHT [x]	R BAUDRATE			
	62K5			

A1:dew-2 09:24:56		F2 →	MODE	
-SETUP-E-LAN	BAUDRATE		4-Wire	
L	MODE		MODE	
LEFT [ ]	2-Wire		2-Wire	
L TERMINATOR	yes			
RIGHT [ ]	R MODE	F4 →		
	2-Wire			
R TERMINATOR	yes			

A1:dew-2 09:24:56		F3 →	TERMINATOR	
-SETUP-E-LAN	BAUDRATE		yes	
L	MODE			
LEFT [ ]	2-Wire		TERMINATOR	
L TERMINATOR	yes		no	
RIGHT [ ]	R MODE	F5 →		
	2-Wire			
R TERMINATOR	yes			

8.4 Status  
(present data of the supervisory unit PAN - D)

Al:dew-209:24:56

SETUP

--4--

General

RS-232

E-LAN

Status

F5

Al:dew-209:24:56

← PAN-D Status(1) →

PANSYS : 01.94

07.07.00

RAM : 256KB

Battery : OK

REG-EIN1: 0000

← →: next/prev. Page

Al:dew-209:24:56

← COM-STATUS →

COM-1 : DCF77

Baud :

Parity:

H/S :

COM-2 : ECL

Baud : 9600

Parity: Off

H/S : Xon/Xoff

Al:dew-209:24:56

← LAN-STATUS →

LAN-L

Baud : 62K5

Mode : 2D+

Users : 0 (0)

LAN-R

Baud : 62K5

Mode : 2D+


Users : 1 (1)

Users total: 2

## 9 Parameterization of the supervisory unit PAN - D

⇒ To be able to give parameters, please set regulator REG-D to operation mode „HAND“.

### Note

Changes in the parameters are not accepted before having switched to operation mode „HAND (MANUAL OPERATION)“ .

Furthermore, when password poll is activated, a valid password must be inserted (see “Poll Password” on page 38).

When setting the limit values >U2 and >>U4, please consider that, in case of a current-depending setpoint value increase in voltage regulator REG-D, the actual setpoint value may deviate from the set setpoint value

For operation principle see page 34.

Al: dew-2		09:24:56
SETUP	<U1 Undervol.	
--1--	>U2 Overvoltage	
	<<U3 Undervoltage	
	>>U4 Overvoltage	
	Inhibit High	

## 9.1 < U1 Undervoltage

Al:dew-2	09:24:56			Al:dew-2	09:24:56
SETUP	<U1 Undervol..	F1	→		+1.0
--1--	>U2 Overvoltage			Setting the Undervoltage	+0.1
	<<U3 Undervoltage			<U1	-5.0 %
	>>U4 Overvoltage			=====	
	Inhibit High			[0% .. -25%]	-0.1
					-1.0

## 9.2 Time Delay < U1 Undervoltage

Al:dew-2	09:24:56			Al:dew-2	09:24:56
SETUP	<U1	F1	→		+10
--2--	>U2			Setting the timedelay <U1	+1
Time until..	<<U3			Undervoltage:	2
	>>U4			=====	s
	Inhibit High			[0 .. 999]	-1
					-10

## 9.3 > U2 Overvoltage

Al:dew-2	09:24:56			Al:dew-2	09:24:56
SETUP	<U1 Undervol..	F2	→		+1.0
--1--	>U2 Overvoltage			Setting the Overvoltage	+0.1
	<<U3 Undervoltage			>U2	15.0 %
	>>U4 Overvoltage			=====	
	Inhibit High			[0% .. +25%]	-0.1
					-1.0

## 9.4 Time Delay < U2 Overvoltage

Al:dew-2	09:24:56			Al:dew-2	09:24:56
SETUP	<U1	F2	→		+10
--2--	>U2			Setting the Time Delay >U2	+1
Time until..	<<U3			Overvoltage:	5
	>>U4			=====	s
	Inhibit High			[0 .. 999]	-1
					-10

## 9.5 << U3 Undervoltage

Al:dew-2	09:24:56		Al:dew-2	09:24:56
SETUP	<U1 Undervol.			+1.0
--1--				
	>U2		Setting the	
	Overvoltage		Unterspannung	+0.1
	<<U3	F3	<<U3	
	Undervoltage		-10.3 %	
			=====	
	>>U4		[0% .. -35%]	-0.1
	Overvoltage			
	Inhibit High			-1.0

## 9.6 Time Delay << U3 Undervoltage

Al:dew-2	09:24:56		Al:dew-2	09:24:56
SETUP	<U1			+10
2--				
Time			Setting the	
until..	>U2		timedelay <<U3	+1
			Undervoltage:	
	<<U3	F3	2	
			=====	
	>>U4		[0 .. 999]	-1
	Inhibit High			-10

## 9.7 >> U4 Overvoltage

Al:dew-2	09:24:56		Al:dew-2	09:24:56
SETUP	<U1 Undervol.			+1.0
--1--				
	>U2		Setting the	
	Overvoltage		Overvoltage	+0.1
	<<U3		>>U4	
	Undervoltage		10.3 %	
			=====	
	>>U4	F4	[0% .. +35%]	-0.1
	Overvoltage			
	Inhibit High			-1.0

## 9.8 Time Delay >> U4 Overvoltage

Al:dew-2	09:24:56		Al:dew-2	09:24:56
SETUP	<U1			+10
2--				
Time			Setting the	
until..	>U2		Time Delay >>U4	+1
			Overvoltage:	
	<<U3		8	
			=====	
	>>U4	F4	[0 .. 999]	-1
	Inhibit High			-10

9.9 Trigger

Al:dew-2 09:24:56			Al:dew-2 09:24:56
SETUP	<U1 Undervol..		+1.0
--1--	>U2 Overvoltase		Setting the Inhibit High +0.1
	<<U3 Undervoltase		25.3 %
	>>U4 Overvoltase		=====
	Inhibit High	F5 →	[0% .. +35%] -0.1
			-1.0


9.10 Time Delay Trigger

Al:dew-2 09:24:56			Al:dew-2 09:24:56
SETUP	<U1		+10
--2--	>U2		Setting the Time Delay Inhibit High: +1
Time until..	<<U3		10 s
	>>U4		=====
	Inhibit High	F5 →	[0 .. 999] -1
			-10




## 9.11 Functions


The title „functions“ in SETUP 3 defines all features and additional functions which may be activated or deactivated or also offer completing features.

Al:dew-2 09:24:56		F1		Al:dew-2 09:24:56	
SETUP	AddOns-1			AddOns-1	
--3--				Activity_Lamp	
	Input			Maximum Time:	3s
	Assignments..			Measurement:	3-phasig
	Relay			Limit Base:	Setpoint
	Assignments..			PAN-D	
	LED			Deactivation:	OFF
	Assignments..				

### 9.11.1 Maximum Time of Tap-changer in operation

Al:dew-2 09:24:56		F2		Activity_Lamp	
AddOns-1				Maximum Time:	3s
Activity_Lamp				Activity_Lamp	
Maximum Time:	3s			Maximum Time:	5s
Measurement:	3-phasig				
Limit Base:	Setpoint				
PAN-D					
Deactivation:	OFF				
				Activity_Lamp	
				Maximum Time:	21s

### 9.11.2 Measuring (of the net voltage)

Al:dew-2 09:24:56		F3		Measurement:	
AddOns-1				Measurement:	3-phasig
Activity_Lamp					
Maximum Time:	3s				
Measurement:	3-phasig			Measurement:	1-phasig
Limit Base:	Setpoint				
PAN-D					
Deactivation:	OFF				


**9.11.3 Limit Value Reference (Reference quantity)**

The parameter limit value reference offers the possibility to send the message to the regulating system if the limit values are to be set relatively to the correspondingly active setpoint value or relatively to the nominal voltage  $U_{nom} = 100\text{ V}$ .

If the parameter „Setpoint value“ is selected and the limit <U1 is set for example to – 10 %, then, the limit value switch <U1 will react as soon as the voltage drops by more than 10 % below the active setpoint value.

If the parameter 'Unom' is selected, the limit value switch <U1 will trigger at a voltage lower than 90 V ( $\hat{=}$  –10 %) regardless to the active setpoint value.

The statements for <U1 apply by analogy for all PAN-D limits which are inserted in %.



## 9.11.4 PAN - D Deactivation

The function 'PAN - D deactivation' is an assisting function for the putting into operation of the regulating system.


During the putting into operation, it is occasionally necessary to drive the transformer over the complete tap-change range by hand.

Should PAN-D be activated, there would only be the possibility to change the voltage within the limits  $<U_1$  and  $>U_2$ .



Should the voltage exceed oder undershoot one of these two values, PAN-D would block all further setting commands to the tap-changer.

The function „PAN - D deactivation“ which may only be switched on in operation mode HAND suppresses as well this blocking as also the reactions on the limits  $<<U_3$  and  $>>U_4$ .

If the regulator is reset to operation mode AUTOMATION, the deactivation will automatically be deleted.

AI:dew-2 09:24:56		PAN-D Deactivation: OFF	
AddOns-1		PAN-D Deactivation: ON	
Activity Lamp			
Maximum Time:	3s		
Measurement:	3-Phase		
Limit Base:	Setpoint		
PAN-D Deactivation:	OFF	<div>F5 </div>	

9.12 Input Assignments (Binary Inputs)



## 9.13 Relay Assignments

Al:dew-2	09:24:56		Al:dew-2	09:24:56
SETUP	AddOns..		Relay	...
--3--			Assignment	...
			[x] Rel 5:	OFF
	Input		[ ] Rel 6:	PROG
	Assignments..		[ ] Rel 14:	EIN
	Relay			
	Assignments..			
	LED			
	Assignments..			



Al:dew-2	09:24:56		Al:dew-2	09:24:56
Relay	...		00:OFF	^
Assignment	...		01:PROG	
[x] Rel 5:	OFF		02:ON	↑
[ ] Rel 6:	PROG		03:<U1	
[ ] Rel 14:	EIN		04:>U2	↓
			05:<<U3	
			06:>>U4	↓
			07:Quick	
			08:Inh. Low	↓
			↑↓ : Select	ESC:
			↓ : OK	Escape



Al:dew-2	09:24:56
Relay	...
Assignment	...
[x] BA 1 :	Inh. Low
[ ] BA 2 :	TC-Err
[ ] BA 3 :	NotAusSt
[ ] BA 4 :	PhasFall

9.14 LED Assignments

Al:dew-209:24:56

SETUP

--3--

AddOns..

Input Assignments..

Relay Assignments..

LED Assignments..

F5

➔

Al:dew-209:24:56

LED Assignment

...

[ ] LED 1 : OFF

[ ] LED 2 : PROG

[ ] LED 3 : <U1

[ ] LED 4 : >U2

Al:dew-209:24:56

LED Assignment

...

[ ] LED 1 : OFF

[ ] LED 2 : PROG

[ ] LED 3 : <U1

[ ] LED 4 : >U2

➔

Al:dew-209:24:56

00: OFF

01: PROG

02: <U1

03: >U2

04: <<U3

05: <<U4

06: Quick

07: Inh\_Low

08: TC-Err

↑↓ : Select ESC: ~

↵ : OK ESC: Escape

Al:dew-209:24:56

LED Assignment







...

[ ] LED 5 : OFF

[ ] LED 6 : PROG

## 10 Update of the Operation Software

To update the operational software, it is necessary to use a Zero modem cable. Due to the high baudrate, however, a hardware Handshake is also required. Therefore the RTS/CTS lines must be linked crosswise.


9-pins Sub-D socket		9-pins Sub-D socket
2 -----		----- 2
3 -----		----- 3
4 -----		----- 4
6 -----		----- 6
7 -----		----- 7
8 -----		----- 8
5 -----	shield	----- 5

## 10.1 Preparing the PC

### 10.1.1 Operation System Windows 3.x

- ⇒ Open window „Control Panel“
- ⇒ Open window „Connections“
- ⇒ Open window „Settings for COM1 and COM2“
- ⇒ Select features
 

Baud (baudrate):	9600 or 38400 or 115200
Data bits:	8
Parity:	none
Stop bits:	1
Protocol:	hardware




- ⇒ Close window by „OK“
- ⇒ Connect cable of the PC to the selected interface COM1 or COM2
- ⇒ Connect cable of the interface COM1 to the supervisory unit PAN-D
- ⇒ Continue with „Start Prime Load“, as shown „Start Prime Load“ on page 58



## 10.1.2 Operation System Windows 95/98


- ⇒ Open window „Control Panel“
- ⇒ Select „Systems“
- ⇒ Select „Device Manager“
- ⇒ Select COM-connection (COM1) or (COM2)
- ⇒ Select characteristics
- ⇒ Select „Connection Settings“
- ⇒ Select features
 


Bits/seconds	9600 or 38400 or 115200
Data bits:	8
Parity:	none
Stop bits:	1
Protocol:	hardware




- ⇒ Close all windows by „OK“
- ⇒ Connect cable of the PC to the selected interface COM1 or COM2
- ⇒ Connect cable of the interface COM1 to the supervisory unit PAN-D


## 10.2 Start Prime Load

In order to make an update of the operation software, the prime load must be started in the supervisory unit PAN-D. To do this, please press down key „TEST“  for approx. 5 s.


When the prime load is activated, the LEDs 'OPERATION' and 'DISTURBANCE' are illuminating at the same time. The set baudrate is displayed on the programmable LEDs and may, resp. must be set to the same value as in the PC by pressing down key „TEST“  .

- ⇔ Programmable LED 1: 115200 Baud
- ⇔ Programmable LED 2: 38400 Baud
- ⇔ Programmable LED 3: 19200 Baud
- ⇔ Programmable LED 4: 9600 Baud

While the key is being pressed down, all LEDs are illuminating. If data is received, the OPERATION-LED is flashing; as soon as there is an error, the DISTURBANCE-LED will start flashing. During the transmission, the data receiving may be aborted by key „TEST“  (then the DISTURBANCE-LED will consecutively start flashing).



- ⇔ RESET: If key „TEST“  is being pressed down for more than 2 s (in this time all LEDs are illuminating), all LEDs will stop to illuminate. If the key is not pressed down any more, a RESET will be executed.

### Note

The prime load may be started again if the key „TEST“  after having been released will be pressed down again until the prime load is loaded (LEDs OPERATION and DISTURBANCE are illuminating).

- ⇔ On part of the PC, the download is made by means of the program „update.exe“.  
The standard of the baudrate is 115200 Baud.  
Windows 3.xx does not support high baudrates > 57600 Baud. This is why, in this case, the download program automatically sets a baudrate of 57600 Baud.  
Therefore the regulator must be adjusted to the same baudrate in this case.

- ⇔ The download itself is being started by menu point Download\alles Updaten (=Download\update all).
- ⇔ The program automatically recognizes if a REG-D or a PAN-D is connected.  
If a recognition is not possible (< prime load version V1.05), the selection will be made by a dialogue.



The further processing runs automatically and at the end of the download is a reset. Then a message box appears which indicates that the instrument is ready to work now.



- ☐ In case of other messages there would be a disruption and the download would have to be repeated again.

## Note

If you may have further questions, please send us an E-mail: „LMeberle@aol.com”

## 11 Maintenance and Current Consumption

### 11.1 How to change fuses

**Caution!**




Before changing fuses, please do separate supervisory unit PAN-D from the power supply!



Required fuse: slow-blowing fuse 250 V, 2 A


You find the fuse holder on terminal block 3



fuse: slow-blowing fuse 2 A


## 11.2 Current Consumption PAN - D

Measuring circuit (100 V DC)



Measuring results

Power-up spike at 100 V DC



## 12 Definition of Abbreviations

Please refer to the operating manual of REG - D.

## 13 Index

### A

Abbreviations 62  
Acknowledgement of messages 32  
Actual Value Correction 39  
aligning plugs 18  
Auxiliary Voltage 13

### B

basic settings 36  
baudrate 55, 58  
Binary Inputs 12, 52  
Binary Outputs 11  
bus link 35

### C

COM 1 16, 40  
COM 2 41  
Connection Terminals 18  
Contact assignment 11  
CPU-Test 24  
Current Consumption PAN - D 61

### D

Delete Passwords 38  
Delivery Contents 8  
Dimensions 9  
Dimensions for the panel section 20  
DIN VDE 0411 6  
Disturbance (red) 26  
Disturbance regulator 32  
Disturbance Tap-changer 30  
download 59

### E

E-LAN 15, 43  
electrical safety 6  
E-mail 59  
Emergency OFF Tap-changer 31  
EN61010 6  
Energy-Local Area Network 23

### F

front plate 9  
Function keys 32  
function keys 34  
fuse 60  
fuses 6

### G

General 36

### H

height 9, 18  
Hole distance 19  
How to change fuses 60  
How to mount PAN - D 18

### I

Identification Signal (User ID) 36  
IEC 10110 6  
Indication and Operation Elements 24  
indication mode 35  
Interface COM 1 16, 22  
interface COM 1 23

### L

LC-display 21, 25

### M

Maintenance and Current Consumption 60  
Maintenance and repair works 6  
malfunction 6  
matching resistors 21  
Material 18  
measuring value simulation 33, 35  
Measuring Voltage 13  
Messages 14  
Mounting assistance 19  
Mounting Location 18  
Mounting rack 18

## N

non-fused earthed conductor 6

## O

Operation 24

Operation (green) 26

Operation Elements 24

Operation Principle 34

overshot 27, 28

## P

panel mounting 19

panel section 19, 20

Password 38

Phase fall (red) 26

Pin assignment of the terminal blocks 17

plug-in connectors 9

Plug-in group 9

plug-in rack 18

Poll Password 38

Position of the Pin-Edge Connectors 10

Position of the Terminal Blocks 10

program "update.exe" 58

programmable LEDs 58

Programmable message boxes with LEDs 32

protection class 9, 18

## R

Rack Mounting 18

RS-232 40

## S

safety regulations 6

Set Date 37

Set Time 37

SETUP 34

Status 44

system bus 21

## T

Tap-changer in operation 30

Technical Data 9

Terminal Block 1 11

Terminal Block 2 12

Terminal Block 3 13

Terminal Block 5 14

Terminal Block 6 15

Test 24

Time delay 29

total system 21

transparent cover 18

Trigger power switch 29

## U

U1 27

U2 27

U3 28

U4 28

undershot 27, 28

update 58

user 29

User 1 38

User ID 36

## W

Warnings and Notes 6

weight 9, 18

width 9, 18

Wrong Password 39

## Z

Zero modem 55