



REGCOMMS

Attachment MIBs




Table of Contents

1.	User guidance	4
1.1	Target group	4
1.2	Warnings	4
1.3	Tips.....	5
1.4	Other symbols.....	5
1.5	Applicable documentation.....	5
1.6	Keeping	5
1.7	Updated documentation	5
2.	Scope of Delivery.....	6
3.	Safety instructions.....	6
4.	MIBs	7
5.	Disassembly & disposal	9
6.	Warranty	9
7.	List of Figures	10
8.	List of Tables	10

1. User guidance

This User Manual is a summary of the information needed for the installation, commissioning and operation of the low-voltage regulator.

Read the User Manual in its entirety and do not use the product unless you have understood the User Manual.


1.1 Target group

The User Manual is intended for skilled technicians as well trained and certified operators. The contents of this User Manual must be accessible to people tasked with the installation and operation of the system.

1.2 Warnings


Structure of the warnings


Warnings are structured as follows:


 SIGNAL WORD	Nature and source of the danger. Consequences of non-compliance. Actions to avoid the danger.
---	--

Types of warnings

Warnings are distinguished by the type of danger they are warning against:

 DANGER!	Warns of imminent danger that can result in death or serious injuries if not avoided.
--	---

 WARNING!	Warns of a potentially dangerous situation that can result in death or serious injuries when not avoided.
---	---

 CAUTION!	Warns of a potentially dangerous situation that can result in fairly serious or minor injuries when not avoided.
---	--

NOTICE:	Warns of a potentially dangerous situation that if not avoided could result in material or environmental damage.
----------------	--

1.3 Tips



Tips on the appropriate device use and recommendations.

1.4 Other symbols

Instructions

Structure of the instructions:

➡ Instructions for an action.

↪ Indication of an outcome, if necessary.

Lists

Structure of unnumbered lists:

○ List level 1

— List level 2

Structure of numbered lists:

1) List level 1

2) List level 1

1. List level 2

2. List level 2

1.5 Applicable documentation

For the safe and correct use of the product, observe the additional documentation that is delivered with the system as well as the relevant standards and laws.

1.6 Keeping

Keep the user manual, including the supplied documentation, readily accessible near the system.

1.7 Updated documentation

The most recent versions of the documents can be obtained at <https://www.a-eberle.de/de/downloads>.

2. Scope of Delivery

3. Safety instructions

- Observe the operating instructions.
- Always keep the operating instructions with the unit.
- Make sure that the device is never operated in a damaged or compromised condition.
- Make sure that only specialized personnel operate the unit.
- The device must be connected according to the manufacturer's installation instructions.
- Make sure that the device is never operated beyond its stated ratings.
- Do not operate the unit in any hazardous environment where explosive gases, dust or fumes occur.
- Ensure that protective covers are always in place and are functional.
- Ensure that the five safety regulations according to DIN VDE 0105 are always observed.
- Clean the appliance only with commercially available detergents.

4. MIBs

In the following is a table shown which includes the available MIB-files generated by the net-snmp.

Table 1: Implemented MIBs of net-snmp

MIBs	comment
AGENTX-MIB	
DISMAN-EVENT-MIB	
DISMAN-SCHEDULE-MIB	
DISMAN-SCRIPT-MIB	
EtherLike-MIB	
HOST-RESOURCES-MIB	
IF-INVERTED-STACK-MIB	
IF-MIB	
IP-FORWARD-MIB	
IP-MIB	
IPV6-ICMP-MIB	
IPV6-MIB	
IPV6-TCP-MIB	
IPV6-UDP-MIB	
NET-SNMP-AGENT-MIB	
NET-SNMP-EXTEND-MIB	
NET-SNMP-VACM-MIB	
NOTIFICATION-LOG-MIB	
RFC1213-MIB	
RMON-MIB	
SCTP-MIB	
SMUX-MIB	
SNMP-COMMUNITY-MIB	
SNMP-FRAMEWORK-MIB	
SNMP-MPD-MIB	
SNMP-NOTIFICATION-MIB	
SNMP-PROXY-MIB	
SNMP-TARGET-MIB	
SNMP-TSM-MIB	
SNMP-USER-BASED-SM-MIB	
SNMP-USM-DH-OBJECTS-MIB	
SNMPv2-MIB	
SNMP-VIEW-BASED-ACM-MIB	

We take care of it.

TCP-MIB	
TUNNEL-MIB	
UCD-SNMP-MIB	
UDP-MIB	

Table 2: MIBs of A-erberle

MIBs	comment
BRIDGE-MIB	
IEC-62439-3-MIB (PRP)	

5. Disassembly & disposal

The disposal of the LVRSys™ is carried out by A. Eberle GmbH & Co. KG.

➔ Send all components to:

A. Eberle GmbH & Co. KG
Frankenstraße 160
D-90461 Nuremberg



6. Warranty

A. Eberle GmbH & Co. KG. warrants that this product and accessories will be free from defects in materials and workmanship for a period of three years from the date of purchase.

Warranty does not apply to damage caused by:

- 0 Accidents
- 0 Misuse
- 0 Abnormal operating conditions

To make a warranty claim, please contact your local A.Eberle distributor or alternatively contact A. Eberle GmbH & Co KG in Nuremberg, Germany

7. List of Figures

Es konnten keine Einträge für ein Abbildungsverzeichnis gefunden werden.

8. List of Tables

Table 1:	Implemented MIBs of net-snmp	7
Table 2:	MIBs of A-eberle.....	8



A. Eberle GmbH & Co. KG

Frankenstraße 160
D-90461 Nuremberg
Germany

Tel.: +49 (0) 911 / 62 81 08-0
Fax: +49 (0) 911 / 62 81 08 96
E-Mail: info@a-eberle.de

<http://www.a-eberle.de>

Presented by:

Copyright 2018 by A. Eberle GmbH & Co. KG

Subject to change without prior notice.